

PLANO DE ESTACIONAMIENTO Y ATRAQUE DE AERONAVES/  
AIRCRAFT PARKING/DOCKING CHART

ELEV AD 5 M


TWR	118.5	ATIS	115.9
TWR/APP	119.9	FPQ	122.3
EMERG	121.5		

AFTN-MMAA

**ACAPULCO**  
AEROPUERTO INTL  
INTL AIRPORT

**GRAL JUAN N. ALVAREZ**

PLATAFORMA DE AVIACION COMERCIAL /  
COMMERCIAL AVIATION APRON  
CONCRETO / CONCRETE  
RESISTENCIA / STRENGTH 103/R/A/X/T



CAMBIOS: SIMBOLOGIA

**COORDENADAS INS, DE PUESTOS DE ESTACIONAMIENTO DE AERONAVES AVIACION COMERCIAL /  
COORDINATES INS, FOR AIRCRAFT STANDS, COMMERCIAL AVIATION APRON**

<b>POSICION/ POSITION</b>	<b>LAT (N)</b>	<b>LONG (W)</b>
<b>1</b>	16° 45' 43.3128"	099° 45' 25.9961"
<b>2</b>	16° 45' 42.8496"	099° 45' 24.5186"
<b>3</b>	16° 45' 42.3061"	099° 45' 22.7841"
<b>4</b>	16° 45' 41.7120"	099° 45' 20.8893"
<b>5</b>	16° 45' 41.3346"	099° 45' 18.9210"
<b>6</b>	16° 45' 40.6795"	099° 45' 16.5871"
<b>7</b>	16° 45' 39.7913"	099° 45' 14.0789"
<b>8</b>	16° 45' 38.9107"	099° 45' 11.9600"
<b>9</b>	16° 45' 38.4567"	099° 45' 10.5143"
<b>10</b>	16° 45' 33.9164"	099° 45' 18.2686"
<b>11</b>	16° 45' 34.3673"	099° 45' 19.8205"
<b>12</b>	16° 45' 34.8546"	099° 45' 21.3630"
<b>13</b>	16° 45' 35.3404"	099° 45' 22.9002"
<b>14</b>	16° 45' 35.8224"	099° 45' 24.4383"
<b>15</b>	16° 45' 36.3323"	099° 45' 25.9770"