

PLANO DE ESTACIONAMIENTO Y ATRAQUE DE AERONAVES /
AIRCRAFT PARKING/DOCKING CHART

ELEV AD 191 M


TWR
APP

118.7
121.4

HERMOSILLO

AEROPUERTO INTL /
INTL AIRPORT

GRAL IGNACIO PESQUEIRA GARCIA



**COORDENADAS INS, DE PUESTOS DE ESTACIONAMIENTO DE AERONAVES AVIACION COMERCIAL /
COORDINATES INS, FOR AIRCRAFT STANDS, COMMERCIAL AVIATION**

POSICION/ POSITION	LAT (N)	LONG (W)	AERONAVE / AIRCRAFT	RESISTENCIA / STRENGTH	TIPO / TYPE
1	29° 05´ 28.57"	111° 03´ 03.58"	B757-200	67/R/B/X/T	CONCRETO / CONCRETE
2	29° 05´ 27.73"	111° 03´ 05.17"			
3	29° 05´ 26.96"	111° 03´ 06.61"	A321-200		
4	29° 05´ 26.20"	111° 03´ 08.05"			
5	29° 05´ 25.40"	111° 03´ 09.44"			
6	29° 05´ 24.79"	111° 03´ 10.87"			
7	29° 05´ 24.06"	111° 03´ 12.24"			
8	29° 05´ 23.23"	111° 03´ 13.52"			
9	29° 05´ 22.53"	111° 03´ 14.82"			
10	29° 05´ 21.83"	111° 03´ 16.13"			
11	29° 05´ 21.12"	111° 03´ 17.46"			
11A	29° 05´ 20.14"	111° 03´ 17.69"	B747-400		
12	29° 05´ 20.42"	111° 03´ 18.78"	A321-200		