


PLANO DE ESTACIONAMIENTO Y ATRAQUE DE AERONAVES/
AIRCRAFT PARKING/DOCKING CHART

ELEV AD 11.5 M

TWR	118.3
APP	121.2
FPQ	122.3
EMERG	121.5

MAZATLAN
AEROPUERTO INTL /
INTL AIRPORT

GRAL. RAFAEL BUELNA



**COORDENADAS INS, DE PUESTOS DE ESTACIONAMIENTO DE AERONAVES AVIACION COMERCIAL /
COORDINATES INS, FOR AIRCRAFT STANDS, COMMERCIAL AVIATION APRON**

POSICION/ POSITION	LAT (N)	LONG (W)
1	23° 09' 58.20"	106° 16' 17.84"
2	23° 09' 56.85"	106° 16' 17.89"
	23° 09' 56.87"	106° 16' 17.85"
	23° 09' 56.94"	106° 16' 17.75"
	23° 09' 56.99"	106° 16' 17.68"
	23° 09' 57.03"	106° 16' 17.62"
3	23° 09' 56.40"	106° 16' 16.84"
	23° 09' 56.65"	106° 16' 16.82"
4	23° 09' 56.58"	106° 16' 15.35"
	23° 09' 56.63"	106° 16' 15.41"
	23° 09' 56.68"	106° 16' 15.46"
	23° 09' 56.72"	106° 16' 15.50"
	23° 09' 56.77"	106° 16' 15.56"
	23° 09' 56.79"	106° 16' 15.58"
5	23° 09' 57.79"	106° 16' 14.98"
	23° 09' 57.80"	106° 16' 15.15"
	23° 09' 57.81"	106° 16' 15.26"
6	23° 09' 57.62"	106° 16' 10.50"
	23° 09' 57.61"	106° 16' 10.33"
	23° 09' 57.60"	106° 16' 10.22"
7	23° 09' 56.39"	106° 16' 10.33"
	23° 09' 56.43"	106° 16' 10.28"
	23° 09' 56.49"	106° 16' 10.19"
	23° 09' 56.55"	106° 16' 10.11"
	23° 09' 56.59"	106° 16' 10.05"
8	23° 09' 56.02"	106° 16' 08.94"
	23° 09' 56.27"	106° 16' 08.93"
9	23° 09' 56.46"	106° 16' 07.74"
	23° 09' 56.39"	106° 16' 07.67"
	23° 09' 56.32"	106° 16' 07.60"
	23° 09' 56.27"	106° 16' 07.56"
10	23° 09' 57.58"	106° 16' 07.53"