

PLANO DE AERODROMO PARA  
MOVIMIENTOS EN TIERRA /  
AERODROME GROUND MOVEMENTS CHART  
(A380, B747-8 & ANTONOV 124)

# RWY 05R

RUTA DE OPERACION DE AERONAVES CLAVE DE REFERENCIA "F"  
RWY 05R-23L EXCLUSIVA PARA SU OPERACION DE DESPEGUE Y ATERRIZAJE /  
OPERATION ROUTE FOR AIRCRAFT CAT "F"  
RWY 05R-23L EXCLUSIVE FOR TAKE OFF AND LANDING

**MEXICO**  
AEROPUERTO INTL/  
INTL AIRPORT  
**BENITO JUAREZ**

A380 Y B747-8 EN SALIDA DE POSICIONES 33A Y 35A,  
SE REALIZARA EL PUSH BACK HACIA EL SUR Y UNA  
VEZ SOBRE EL RODAJE "B" SERAN REMOLCADAS  
AL PUNTO DE ENCENDIDO DE MOTORES ANTES DE  
LA SALIDA DEL SEI  
A380 AND B747-8 LEAVING GATES 33A AND 35A SHALL  
PUSH BACK TO THE SOUTH, ONCE ON "B" BE TOWED  
TO THE START UP POINT BEFORE SEI EXIT

A380 Y B747-8 EN ENTRADA A POSICION 35A,  
DEBERAN ESTAR LIBRES POSICIONES 34, 35  
Y 36 O 33A UNICAMENTE CON AERONAVES  
CLAVE DE REFERENCIA "E".  
FOR A380 AND B747-8 TO ENTER GATE 35A,  
GATES 34, 35 AND 36 MUST BE EMPTY OR 33A  
ONLY FOR AIRCRAFT REFERENCE CODE "E"

B747-8 EN SALIDA DE POSICION 26, SE  
REALIZARA EL PUSH BACK HACIA EL  
SUR Y UNA VEZ SOBRE EL RODAJE "B"  
EFECTUARA EL ENCENDIDO DE MOTORES.  
B747-8 LEAVING GATE 26 WILL PUSH BACK  
TO THE SOUTH, ONCE IN "B" WILL PERFORM  
ENGINE START-UP

A380 EFECTUARA CARRETEO EN RUTA ESTABLECIDA CON MOTORES  
2 Y 3 DE MANERA NORMAL, MANTENIENDO MOTORES 1 Y 4 AL RALENTI/  
A380 WILL TAXI AS PER ESTABLISHED ROUTE, WITH POWER FROM  
ENGINES 2 AND 3, DEEPIING ENGINES 1 AND 4 AT IDLE.

PARA EL CRUCE DE PISTAS, SE EFECTUARA PREFERENTEMENTE SIN  
MANTENER ENTRE PISTAS, CON UNA SOLA AUTORIZACION/  
FOR RUNWAYS CROSSING, A SOLE CLEARANCE WILL BE ISSUED  
PREFERABLY TO AVOID HOLDING BETWEEN RUNWAYS.

RUTA ALTERNA POR RODAJES CERRADOS O DESTINO HANGAR  
COORDINAR CON COMANDANCIA /  
AN ALTERNATE ROUTE DUE TO CLOSED TAXIWAYS OR BOUND TO  
HANGAR, SHALL BE COORDINATED WITH THE AIRPORT AUTHORITY.

CABECERA 05R EN USO / RUNWAY HEAD 05R IN USE:

- ← LLEGADAS / ARRIVALS → SALIDAS / DEPARTURES
- ← LLEGADAS UNICAMENTE B747-8 A POS. 26, 41A, 43, 45 Y 46A /  
ARRIVALS B747-8 TO GATE 26, 41A, 43, 45 AND 46A ONLY
- ← SIN CARRETEO DE AERONAVES CLAVE DE REFERENCIA "F" /  
NO TAXIING FOR AIRCRAFT WITH REFERENCE CODE "F"
- ← CON CARRETEO DE AERONAVES A380 Y B747-8 EN RODAJE "B",  
UNICAMENTE TRANSITO DE AERONAVES B767 Y MENORES EN  
RODAJE "C".  
WHILE A380 AND B747-8 TAXIING ON "B", ONLY B767 AND  
SMALLER AIRCRAFT TO TAXI ON "C"

## PUESTOS DE ESTACIONAMIENTO AUTORIZADOS / APPROVED PARKING PLACES

A380 (33A, 35A)  
B747-8 (26, 33A, 35A, 41A, 43, 45, 46A)  
AN124 (41A, 46A)

ZONA SIN VISIBILIDAD DESDE TWR, PRECAUCION AL TRANSITAR  
ZONE OUT OF SIGHT FROM TWR, PROCEED CAUTIOUSLY

ESCALA / SCALE : 1 : 18000

0 200 400 600 800 1000 M

CAMBIO: SIMBOLOGIA