

PLANO DE ESTACIONAMIENTO Y ATRAQUE DE AERONAVES/
AIRCRAFT PARKING/DOCKING CHART

ELEV AD 4.5 M


TWR	118.0
ATIS	127.8
VOR/DME	112.5
APP/CUN	124.7
ARR/CUN	123.2

COZUMEL
AEROPUERTO INTL /
INTL AIRPORT

**CALLES DE RODAJE, ANCHO, RESISTENCIA /
TAXIWAYS, WIDTH, STRENGTH**

TWY	ANCHO / WIDTH	RESISTENCIA / STRENGTH	TIPO / TYPE
A	23 M	16/F/B/Y/T	ASFALTO / ASPHALT
D		60/F/A/X/T	
E			
F		64/F/B/X/T	

PLATAFORMA DE AVIACION COMERCIAL /
COMMERCIAL AVIATION APRON
PSN 1 : 64/F/B/X/T ASFALTO / ASPHALT
66/R/B/W/T CONCRETO / CONCRETE
PSN 2-6: 64/F/B/X/T ASFALTO / ASPHALT



**COORDENADAS INS DE PUESTOS DE ESTACIONAMIENTO DE AERONAVES AVIACION COMERCIAL /
COORDINATES INS, FOR AIRCRAFT STANDS, COMMERCIAL AVIATION**

POSICION/ POSITION		LAT (N)	LONG (W)
P01	P01A	20° 30' 41.39"	086° 55' 45.32"
	P01B	20° 30' 41.75"	086° 55' 45.13"
	P01C	20° 30' 43.02"	086° 55' 44.49"
P01A	P1AA	20° 30' 42.32"	086° 55' 47.10"
	P1AB	20° 30' 42.39"	086° 55' 46.64"
	P1AC	20° 30' 43.00"	086° 55' 44.46"
P02	P02A	20° 30' 41.96"	086° 55' 46.58"
	P02B	20° 30' 42.32"	086° 55' 46.40"
	P02C	20° 30' 43.59"	086° 55' 45.75"
P03	P03A	20° 30' 42.53"	086° 55' 47.84"
	P03B	20° 30' 42.90"	086° 55' 47.65"
	P03C	20° 30' 44.16"	086° 55' 47.01"
P04	P04A	20° 30' 43.10"	086° 55' 49.10"
	P04B	20° 30' 43.47"	086° 55' 48.91"
	P04C	20° 30' 44.73"	086° 55' 48.27"
P05	P05A	20° 30' 43.67"	086° 55' 50.36"
	P05B	20° 30' 44.04"	086° 55' 50.17"
	P05C	20° 30' 45.30"	086° 55' 49.53"
P05A	P5AA	20° 30' 43.51"	086° 55' 49.83"
	P5AB	20° 30' 43.93"	086° 55' 50.09"
	P5AC	20° 30' 45.86"	086° 55' 50.76"
P06	P06A	20° 30' 44.24"	086° 55' 51.62"
	P06B	20° 30' 44.61"	086° 55' 51.43"
	P06C	20° 30' 45.87"	086° 55' 50.79"